

## Aprilia Display Cheat Sheet

### Left Display:

#### Settings:

**km/h <-> mph:** A(5 sec), B, A(5 sec)

**Reset service indication:** Lap, R(5 sec)

#### While stationary:

**Reset trip counter:** R(2 sec)

**Show max. speed:** B(1 sec)

**Reset max. speed:** B(1 sec), R(2 sec)

**Show avg. spd & 2nd trip:** B(1 sec), B(1 sec)

**Reset avg. spd & 2nd trip:** B(1 sec), B(1 sec), R(1 sec)

### Lap Timer:

**Enable:** Lap, D

**Start timer:** Lap

**Lap time:** Lap (display lap time & start new lap)

**Display stored times:** B, Lap (cycle through up to  
40 laps)

**Return to lap timer:** B

**Reset stored lap times:** A + Lap(2 sec)

**Exit lap timer:** Lap + D

### Right Display:

#### D cycles:

- Temp & Time
- Batt. Voltage
- Clock: Set hours
- Clock: Set minutes
- Temp: Set deg. C/F

*(Lap to set hours/minutes/units)*

### Display Test:

Switch on ignition while  
pressing A + B

### Rev limit indicator:

**Set:** C, C(hold/press  
repeatedly)

**Show:** C(short)

*(Rev limit indicator can only  
be set with engine off)*

### Legend:

*"A(5 sec)" means press button A for 5 seconds*

*"A + Lap" means press button A and the Lap button together*

*This reference applies to Aprilia V-Twins  
RSV Mille and SL Mille*

*(c) 2001 Markolf Gudjons <adcs@mtnsb.org>  
All rights reserved - duplication for private use permitted*